

**PHILIPS**

dynalite 

# DBC1205

12 x 5A HF Ballast Controller  
Installation Manual



## Contents

Warning.....	2	Hardware Controls.....	7
Features.....	2	Troubleshooting.....	8
Important Safeguards.....	2	Specification.....	8
Internal View.....	3		
Mounting.....	4		
Supply & Load Cable Connections.....	5		
Connecting Serial Control Cables.....	6		

Supplied by:



Melbourne  
03 9701 2500

Sydney  
02 9737 8988

info@lightmoves.com.au

www.lightmoves.com.au



### Warning

- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS DEVICE TO RAIN OR MOISTURE.
- DO NOT ENERGISE UNLESS THE FRONT COVER IS IN PLACE.
- THIS DEVICE MUST BE EARTHED.
- INSTALLATION, PROGRAMMING AND MAINTENANCE MUST BE CARRIED OUT BY QUALIFIED PERSONNEL

## features

- **Single or multi Phase Supply**  
Single phase and neutral at 60A or 3 phase and neutral at 20A per phase.
- **12 Switched Outputs**  
Each 5A output is switched via a high specification relay with specially treated contacts which prevent contact fusion when switching very reactive loads.
- **12 Control Outputs**  
The 12 control outputs can be configured to be either 1-10V, or DSI serial control, covering the latest types of HF Fluorescent Ballasts. Also compatible with 1-10V and DSI dimmable electronic transformers.
- **MCB Protection**  
Each group of 4 channels is protected by a single pole magnetic circuit breaker.
- **Many Control Options**  
Control of this device can be from a combination of methods, eg. serial control port, relay contacts, push button wall stations, infra red receivers and timeclocks. Easy high-level interface to other popular AV control systems and Building Management Systems (BMS) is also available.
- **Simple Installation**  
Wall-mount enclosure with mounting lugs facilitates installation. Cable knockouts are provided, at the top of the enclosure for supply and load cables, with low voltage (LV) control at the bottom.

## important safeguards

**Warning** – This is a class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

**Read Instructions** – We recommend that you read this instruction manual prior to commencement of installation. Retain instructions and give the end user

**Troubleshooting** - If problems are encountered, check the troubleshooting section on page 10.

**Special Programming** – Once powered and terminated correctly this device will only operate in basic mode. A new Dynalite panel will turn on all lighting channels from button 1 and turn off from button 4 if network terminations are correct. Only once the full network is test correct can commissioning begin. Advanced functions can be commissioned via Envision software. If commissioning is required, contact your local distributor for details.

**Check Connections** – Treat this device as a switchboard that has been shipped. Tighten all load-carrying screw connections, as vibrations from transport can cause MCB and terminal block screws to become loose.

**Power Sources** – This device should only be operated from the type of supply specified on the front panel. This device *must* be earthed.

**Output Circuits** – The load on a circuit should not exceed the specified capacity of 5A. Loads should be calculated to ensure that the overall maximum capacity of 60A is not exceeded.

**Load Control Circuits** – If this device is being used to control 1-10V or DSI HF fluorescent ballasts, a 2 core mains rated control cable is required to be run to the loads, in addition to the mains feed.


**Load Type** – Default settings are for load control outputs to be 1-10V. Check to see what type of HF Fluorescent Ballasts are in the luminaries. Do not terminate the control lines to any DSI loads until the relevant channel has been programmed as DSI. When connecting 1-10V load control lines, pay attention that the correct polarity is maintained.

**Megger Testing** – Do not megger test any circuitry connected to the dimming system, as damage to the electronics may result.

**Mounting Location** – This device must be mounted right way up, on a vertical surface (refer to page 4 for mounting instructions). The specified minimum clearance of 100mm for all sides must be adhered to. Install in a dry, well-ventilated location. Controllers may emit some mechanical noise. Take this into account when deciding the mounting location.





**Data Cable** – The recommended cable for connections to the serial port is screened, stranded RS485 data cable with three twisted pairs. Part numbers for various manufacturers are listed on page 6. This cable should be segregated from mains cables by a minimum distance of 300mm. If anticipated cable runs are over 600 metres for serial cables, consult your dealer for advice. Do not cut or terminate live data cables.

# internal view



For spare parts, please call your nearest Dynalite Customer Service Centre, and specify **DBC1205**

# mounting



## Select A Suitable Location

This device is designed for indoor use only. If installing in an external location, the DBC1205 must be housed in a suitable well-ventilated enclosure. Choose a dry location, that will be accessible after the installation is complete. The DBC1205 should be mounted *vertically, the right way up*. An air gap of 200mm on each side and at the top and bottom of the device should be adhered to. This air gap is required to ensure the serviceability of the DBC1205 without its complete removal from the mounting surface. This device may emit some mechanical noise. Take this into account when deciding the mounting location.


## Fixing the Device

The DBC1205 has integral mounting brackets attached to the enclosure. The brackets are designed to accommodate 4 fixing screws up to 8mm diameter. The DBC1205 can be fixed to the wall without opening the cabinet or removing covers. Make sure no dust or other debris enters the device during installation. Do not leave the front cover off for any length of time. Excessive dust and dirt can degrade the cooling of the internal components.

## Allow for Cable Entry

Supply and load cables enter the enclosure at the top. If these cables are fed from below the mounting position, they should be routed around the enclosure to enter at the top. An alternative method is to stand the enclosure off from the mounting surface by mounting it on a cable tray or a Unistrut style product. The cables can then be routed between the enclosure and the mounting surface, and enter the enclosure via the cutout provided on the mounting face. The control cables enter at the bottom of the enclosure. Control cables should never be run in the mains voltage sections of the enclosure.

# supply & load cable connections



## Supply Cables

The supply input terminals are located toward the top of the enclosure and consist of Earth, Neutral and 3 Phases, which will accept up to 10mm<sup>2</sup> cables. The supply cables should have a capacity of 20A per phase, to allow the device to be loaded to its maximum capacity.

## Load Cables

Load cables can be terminated on the 12-way Load and neutral terminal strip (one for each channel), and an Earth link located at the centre of the enclosure. These connectors will accept up to 6mm<sup>2</sup> cables. *It is important that an individual output circuit is not overloaded.* Calculate the intended load, and ensure that it is below the maximum capacity of an individual channel, which is 5A. To ensure compliance with interference standards, the load neutral cables must be individually connected to the neutral link terminals inside the cabinet. *Never use a common neutral at a remote location.*

## Load Control Cables


Load control cables can be terminated on the 2 x 12 way terminal strips located directly above the load terminals. The left terminal block is the output for 1-10V, or DSI if selected by software setup. Note that most 1-10V HF fluorescent ballast control wiring is polarity conscious. The +terminal of the ballast connects to the left terminal block, and the – terminal connects to the right (common) terminal block. DSI ballasts are not polarity conscious.

## Energising the Device


If it is necessary to energise load circuits before any control cables are connected, it is acceptable to replace the cover and energise the device immediately, as the default factory programming is to have all channels set to 100% output. If there is no output on any or all channels, see the troubleshooting section (page 10). This device should be de-energised before terminating the control and data cables.

# connecting serial control cables

## Connect Data Cable in a 'Daisy Chain'



## RJ12 Socket Connections



## Determine Your Requirements

Serial ports are used to interconnect other dimmers, smart control panels, sensors and AV controllers. Serial port devices can be identified by 4 terminals, labelled: GND, DATA+, DATA-, +VE.

## Serial Cable Connections

There is one RS485 port for DyNet signals, in the form of a RJ12 socket, on the front panel, which is used for the temporary connection of a PC or a DDP601 Portable Programmer. There are data terminals on the control card, for permanent connections. The recommended cable for connections to the serial port is screened, stranded RS485 data cable with three twisted pairs. Recommended cable types include:

Belden:	9503
Dynalite:	DYNET-STP-CABLE
Garland:	MCP3S
Hartland:	HCK603
M&M Cable:	B2003CS
M&M Cable:	B9503CS
Multicables:	AWM E120236 2092 20
RS Components:	368-687
Dynalite	DYNET-STP-CABLE


One pair is paralleled for GND, one pair paralleled for +VE and one pair used for DATA+ and DATA-.

## Recommended Cable Colour Coding

- Green/White pair:* Paralleled for GND
- Orange/White pair:* Paralleled for +VE
- Blue/White pair:* Blue for DATA+
- White for DATA-
- Brown/White pair:* Spare or for Join

The colour-coding scheme used is not critical, as long as the same scheme is used throughout the installation.

## Serial Cable Permanent Connections



## Serial Cable Connecting Method

The recommended connecting method is to 'daisy chain' devices (starting at the first device, then looping in then out of devices, with a single cable terminating at the last device. There should not be any spurs or stubs, and only the first and last device should terminate one cable. All other devices should terminate two cables). Devices may be wired in any order. The data cable should be segregated from any mains cables. *A data cable that is connected to an energised dimmer is live. Do not cut or terminate live data cables.* If the data cable has to cross over any mains cables, it is recommended that it do so at a 90° angle.

# Connecting Serial Control Cables

---

**AUX Input** - This is a dry contact interface that is active low. The dry contact is connected between the AUX and GND terminals on the DyNet connector strip. The function of the AUX input is programmable. Ensure that the cable length between the dry contact and terminal strip is no longer than 2 metres.

**Service LED** - The Service LED has 3 signalling modes, which are useful for troubleshooting:  
Blinking slowly (1Hz) = Normal Operation  
Blinking fast (4Hz) = Network Activity Detected  
On = Fault

**Service Switch** - The Service Switch has three functions:  
1 push = Transmit Network ID  
3 pushes = All Channels 100%  
Push & hold for 4 sec = Reboot

**Top Set** - This adjusts the maximum output that all other control sources can select, ie: if the Top Set is fully clockwise, 100% selected by a control source will give 100% output. If it is fully anti-clockwise, 100% selected by a control source will give 50% output. This control is useful for extending lamp life and can be operated without any form of network control, effectively turning the device into a stand-alone power conditioner and lamp protector.

**Accessory Module Socket** - Accepts plug in modules for optional features such as DMX512 ports and Time clocks. Consult your distributor for details on the available accessory modules.

# Notes

Check the following list. If you are still unable to rectify the situation, contact your nearest Dynalite office. A complete list of distributors worldwide can be found on the Internet at:

[www.philips.com/dynalite](http://www.philips.com/dynalite)

Please ensure that you have completed the following prior to calling our technical support department.

- Check all symptoms in the Troubleshooting list
- Check for any deviations between the installation and the installation instructions
- Make a list of the model numbers of all devices used in the system

SYMPTOM	PROBABLE CAUSE	ACTION
Dimmer does not operate at all. No Service LED activity. Power supply indicator LED on PCB not lit.	Incorrect connection of mains supply or no power available.	Check power supply to dimmer. Check Line and Neutral input connections.
Power supply indicator LED lit, but no Service LED activity.	Supply voltage too low, short circuit on network. Control PCB faulty.	Check supply voltage is at least 75% of rated voltage. Check 5V & 12V terminal voltages, 5V supply must be present. Disconnect network bus and restore power. Replace control PCB.
Dimmer will not respond to control panel push buttons.	Control panel incorrectly wired. Incorrect configuration.	Check operation of LEDs on control panel. Push button on panel and study response of service LED.
Dimmer operates properly but circuit breakers keep tripping.	Instant tripping: - short circuit on load. Delayed tripping: - Dimmer overloaded.	Check load wiring for short circuits. Verify dimmer loading with current tester (don't forget to de-rate for low power-factor loads and transformer losses). Check that the breaker terminals are tight.
Fluorescent lights won't dim.	Wrong type of ballast or ballast incorrectly wired. Control cable from dimmer to ballasts not installed.	Check ballast type. Check actual wiring against ballast manufacturer's diagram. Check 1-10V/DSI cable and settings.

## specification

<b>Supply:</b>	230V ± 14% 50/60Hz Single Phase at 60A or 230V ± 14% 50/60Hz 3-Phase Y at 20A per phase
<b>Line Outputs:</b>	12 x Switched outputs at 5A per channel (total device load 60A)
<b>Control Outputs:</b>	12 x load control outputs, selectable to 1-10V or DSI
<b>Protection:</b>	3 x 20A 6kA single pole thermal magnetic circuit breakers
<b>Switching Device:</b>	Relay – 10A nom. (resistive)
<b>Control Inputs:</b>	1 x RS485 DyNet serial port 1 x programmable dry contact AUX input
<b>User Controls:</b>	Service switch Diagnostic LED
<b>Internal Controls:</b>	Programmable Logic Controller Dynalite Accessory Module enabled
<b>DyNet DC Supply +VE:</b>	90mA (supply for approx. 4 panels)
<b>Preset Scenes:</b>	170
<b>Supply Terminals:</b>	Line1, Line2, Line3 1 x 16mm <sup>2</sup> max conductor size
<b>Output Terminals:</b>	Line, Neutral for each channel 2 x 4mm <sup>2</sup> max conductor size Earth link bar provided 0V/DSI, +V/DSI for each channel 1 x 2.5mm <sup>2</sup> max conductor size
<b>Cable Entries:</b>	Mains – 1 x 75mm x 53mm removable gland plate Data – 1 x 25mm dia. knockout
<b>Diagnostic Functions:</b> <small>(DTK600, DLight or BAS interface required for displaying and analysing diagnostic data)</small>	Device online/offline status Circuit breaker trip monitoring (optional) Current measurement (optional) Circuit run time tracking (optional)
<b>Compliance:</b>	CE, C-Tick
<b>Ambient Temperature:</b>	0°C - 50°C ambient temperature, 0% to 95% RH non condensing
<b>Construction:</b>	Alloy/Steel wall mount case with epoxy finish
<b>Dimensions:</b>	H 450mm x W 225mm x D 75mm (excludes wall brackets)
<b>Weight:</b>	5.2 Kilograms