



ICON-800 Family Recessed Downlights

Installation Instructions



For more information please contact

lightmoves (03) 9701 2500
info@lightmoves.com.au

138-146 Browns Rd, Noble Park VIC 3174

DW: Icon 800 Installation

Ver 1.2 06 October 2009

1. Cut hole in ceiling 70mm, nominal.
2. Connect the power supply lead to the luminaire and place the power supply in the ceiling space
3. Connect the power supply to the circuit, ensuring it is INACTIVE: Do not turn power on until the light fitting has been connected to the power supply. Failure to observe this requirement may cause damage to the LED circuit board and will VOID WARRANTY
4. Bend the two support springs back carefully toward the heat sink whilst inserting the luminaire, heatsink first, into the ceiling space
5. When the springs have fully entered the ceiling space, slowly release them, whilst holding the lower bezel of the fitting with the other hand
6. Remove your fingers from the ceiling space whilst slowly allowing the fitting to pull into the ceiling space under its own spring action DO NOT let the fitting 'snap' into position
7. Please note the adjustable version of the fitting may only be adjusted fore and aft (in one plane) it is not able to be rotated, so it is important that the fitting is placed to ensure that the direction of adjustment is at 90 degrees to the wall, or illuminated surface at the time of installation

For any technical information relating to the connection of these luminaires to dimming systems, refer to LED products at www.digilin.com.au



For more information please contact

lightmoves (03) 9701 2500
info@lightmoves.com.au

138-146 Browns Rd, Noble Park VIC 3174