

ColorReach Compact Powercore

Premium long-throw compact exterior LED floodlight with intelligent color light



ColorReach Compact Powercore

Premium long-throw compact exterior LED floodlight with intelligent color light

ColorReach Compact Powercore combines all the benefits of LED-based lighting and control in a compact fixture specifically designed for large-scale installations, such as commercial skyscrapers, casinos, bridges, piers, public monuments, and themed attractions. With levels of light output and projection never before achieved in a compact LED lighting fixture, ColorReach Compact Powercore delivers intense, energy-efficient output at a reasonable price, opening up new possibilities for exterior illumination. Custom configurations with custom channels of white or color LED sources are also available to support special applications.

- Integrates Powercore technology Powercore technology rapidly, efficiently, and accurately controls power output to fixtures directly from line voltage. Philips Data Enabler Pro merges line voltage and control data and delivers them to fixtures over a single standard cable, dramatically simplifying installation and lowering total system cost.
- Versatile optics Exchangeable spread lenses of 8°, 13°, 23°, 40°, 63°, and an asymmetric 5° x 17° support a variety of photometric distributions for a multitude of applications, including spotlighting, wall grazing, and asymmetric wall washing. Bezel and gasket are included with spread lenses for easy user installation.
- Saturated, cost-effective color Highperformance LEDs offer rich, saturated color at significantly less cost for installation, operation, and maintenance than traditional light sources.

- Simple fixture positioning Rugged, slim-profile
 mounting bracket allows simple positioning and
 fixture rotation through a full 360°. Side locking
 bolts reliably secure fixture with a standard
 wrench.
- Universal power input range Accepts a universal power input range, allowing consistent installation in any location around the world.
- Industry-leading controls Works seamlessly with the complete Philips Color Kinetics line of controllers, including Light System Manager, iPlayer 3, and ColorDial Pro, as well as thirdparty controllers.



Intense light output ColorReach Compact Powercore outputs thousands of lumens and throws light hundreds of feet, delivering legitimate LEDbased illumination of large-scale structures and objects in a compact, fully-sealed housing.

Photometrics / ColorReach Compact Powercore


Photometric data is based on test results from an independent NIST traceable testing lab. IES data is available at www.philipscolorkinetics.com/support/ies.

5° (no spread lens)



LED	Lumens	Efficacy
RGB	4505	36.8

Polar Candela Distribution



		0.5	45	70	00
	0	25	45	70	90
0	271369	271369	271369	271369	271369
5	49083	54543	55596	55014	56479
15	465	469	485	503	528
25	141	143	150	158	177
35	79	76	80	79	107
45	49	47	47	48	48
55	39	43	36	40	39
65	36	32	31	33	32
75	29	25	25	25	25
85	23	23	23	23	23
90	23	22	0	0	0

Illuminance at Distance

	Center Beam fc	Beam	Width
4 ft	16,961 fc	0.5 ft	0.4 ft
8 ft	4,240 fc	0.9 ft	0.9 ft
12 ft	1,884 fc	1.4 ft	1.3 ft
	1.060 fc	1.9 ft	1.7 ft
16 ft	678 fc	2.3 ft	2.2 ft
20 ft			
24 ft	471 fc	2.8 ft	2.6 ft

520 ft (158.5 m) 1 fc maximum distance

Vert. Spread: 6.6°
Horiz. Spread: 6.2°

Coefficients Of Utilization - Zonal Cavity Method

								Effec	tiv	e Fi	loor	Cav	ity	Ref	lecta	ance	: 2	0%
RCC %:		8	0			7	0			50			30			10		0
RW %:	70	50	30	0	70	50	30	0	50		20		30	20	50	30	20	0
RCR: 0								100										
1								99										
2								98								100	99	97
	111												100	99			98	96
	109	105	103	101	108	105	102	96	103	101	99	101	99	98	99	98	97	96
5	108	104	101	99	107	103	100	96	102	99	98	100	98	97	99	97	96	95
6	106	102	100	98	105	102	99	95	101	98	97	99	98	96	98	97	96	95
7	105	101	98	97	104	101	98	95	100	98	96	99	97	96	98	96	95	94
8	104	100	98	96	104	100	97	95	99	97	95	98	96	95	98	96	95	94
9	103	99	97	95	103	99	97	94	98	96	95	98	96	95	97	96	94	94
10	103	99	96	95	102	98	96	94	98	96	94	97	96	94	97	95	94	93

Zonal Lumen


	Z	one	Lumens	%	Fixture	
0	-	60	4419.9		98.1 %	
60	-	90	84.9		1.9 %	
Ω	_	90	4504 8		100 0 %	

8° spread lens



LED	Lumens	Efficacy
RGB	4111	32.3

Polar Candela Distribution



0	25	45	70	90
141546	141546	141546	141546	141546
51073	54259	54274	56276	58731
634	643	668	690	714
169	169	173	173	185
96	95	91	90	109
54	51	49	51	52
40	41	35	37	37
31	30	27	27	27
24	23	22	22	22
21	20	20	20	20
20	20	0	0	0
	141546 51073 634 169 96 54 40 31 24	141546 141546 51073 54259 634 643 169 169 96 95 54 51 40 41 31 30 24 23 21 20	141546 141546 51073 54259 54274 684 668 169 169 173 96 95 91 544 51 49 40 41 35 31 30 27 24 23 22 21 20 20 20	141546 141546 141546 141546 51073 54259 54274 56276 634 663 668 690 169 169 173 173 96 95 91 90 54 51 49 51 40 41 35 37 31 30 27 27 24 23 22 22 21 20 20 20

Illuminance at Distance

	Center Beam fc	Beam Width				
4 ft	8,847 fc	0.6 ft 0.6	ft			
8 ft -	2,212 fc	1.2 ft 1.2	ft			
12 ft	983 fc	1.8 ft 1.8	ft			
	553 fc	2.4 ft 2.3	ft			
16 ft	354 fc	3.0 ft 2.9	ft			
20 ft	22.11					
24 ft	246 fc	3.6 ft 3.5	tt			

376 ft (114.6 m) 1 fc maximum distance ■ Vert. Spread: 8.5°
■ Horiz. Spread: 8.4°

Coefficients Of Utilization - Zonal Cavity Method

								Effec	tiv	e F1	oor	Cav	ity	Ref	lecta	ance	: 2	0%
RCC %:		8	0			7	0			50			30			10		0
RW %:	70			0			30			30					50		20	0
RCR: 0	119	119	119	119	116	116	116	100	111	111	111	106	106	106	102	102	102	100
1	116	114	112	111	113	112	111	98	108	107	106	104	104	103	101	100	100	98
	113																98	97
	111																97	96
	109													97	99	97	96	95
	107														98		95	94
6	106	102	99	97	105	101	98	94	100	98	96	99	97	95	98	96	95	94
7	105			96	104	100	97	94	99	97	95	98	96	95	97	95	94	93
	104	99						93				97	95	94	97	95	94	93
	103			94						95		97		93	96		93	93
10	102	97	95	93	101	97	95	93	97	95	93	96	94	93	96	94	93	92

Zonal Lumen


Zone	Lumens	% Fixture
0 - 60	4035.4	98.2 %
60 - 90	75.1	1.8 %
0 - 90	4110.6	100.0 %

13° spread lens




LED	Lumens	Efficacy
RGB	4053	31.8

Polar Candela Distribution



	0	25	45	70	90
0	80949	80949	80949	80949	80949
5	46190	46041	45544	45473	46699
15	1520	1484	1350	1197	1167
25	182	182	181	178	183
35	103	101	96	94	105
45	57	54	51	51	53
55	40	38	36	36	36
65	30	30	28	28	27
75	24	23	22	22	22
85	20	20	20	20	20
90	20	0	0	0	0

Illuminance at Distance



285 ft (86.8 m) 1 fc maximum distance Vert. Spread: 11.9°
Horiz. Spread: 10.7°

Coefficients Of Utilization - Zonal Cavity Method

1									Effec	tiv	e Fi	loor	Cav	ity	Ref	lect	ance	: 2	0%
RCC	%:		8	0			7	0			50			30			10		0
RW		70		30	0	70			0	50		20	50	30		50	30	20	0
RCR:												111							
1												106							98
1												102		101	100	100	99	98	96
1											101		101		98		97	96	95
	4	108	104	101	99	107	103	100	94	101	99	97	99	98	96	98	96	95	94
						105									95			94	93
						104					96				93				92
					94	102	98	95	92	97	95	93	96	94	92	95	93	92	91
1		102				101	97	94	91				95	93	92	95	93	91	91
		101			91				91	95	93	91	95	92	91	94	92	91	90
	10	100	95	92	91	99	95	92	90	94	92	90	94	92	90	93	91	90	89

Zonal Lumen


	Zone	Lumens	% Fixture
0	- 60	3979.5	98.2 %
60	- 90	73.9	1.8 %
0	- 90	4053.4	100.0 %

23° spread lens




LED	Lumens	Efficacy
RGB	4063	32.0

Polar Candela Distribution



	0	25	45	70	90	
0	21836	21836	21836	21836	21836	
5	18700	19044	19314	19604	19751	
15	6286	6627	6843	7046	7140	
25	850	900	916	939	955	
35	131	132	130	131	133	
45	69	69	67	67	68	
55	48	47	46	45	45	
65	35	35	34	33	33	
75	26	26	25	24	24	
85	20	20	20	20	20	
90	19	9	7	3	0	

Illuminance at Distance



Coefficients Of Utilization - Zonal Cavity Method

								Effec	tiv	e F1	oor	Cav	ity	Ref	lecta	ance	: 20	0%
RCC %:		8	0			7	0			50			30			10		0
RW %:	70	50	30	0	70	50	30	0	50	30	20	50	30	20	50	30	20	0
RCR: 0	119	119	119	119	116		116				111			106		102	102	100
1	115	112	110	109	112	110	109	96	106	105	104	103	102	101	99	98	98	96
2					109					100	98	99	98	96	97	95	94	93
3	107	102					98	90	99	96	94	96	94	92	94	92	91	89
4	104		95	91	102	97	94	87	96	92		94	91		92	90	88	87
	101	95	91	88	100	94	90	85	93	89	87	91	88	86	90	87	85	84
6		92	88	85	97	91	87	83	90	87	84	89	86	83	88	85	83	82
7		89	85	82	95	89	85	81	88	84		87	83	81	86	83	81	80
8		87	83	80	92	86	82	79	85	82	79	84	81	79	84	81	79	78
6		84	80	78	90	84	80	77	83	80	77	82	79	77	82	79	77	76
10	89	82	78	76	88	82	78	75	81	78	75	81	77	75	80	77	75	74

Zonal Lumen


	Z	one	Lumens	% Fixture
0	-	60	3981.5	98.0 %
60	-	90	81.6	2.0 %
0	_	90	4063 1	100.0 %

40° spread lens




LED	Lumens	Efficacy
RGB	4028	31.6

Polar Candela Distribution



	0	25	45	70	90
0	7659	7659	7659	7659	7659
5	7135	7226	7287	7380	7432
15	4812	4985	5142	5340	5442
25	2266	2399	2536	2720	2812
35	719	778	840	930	981
45	177	193	202	220	235
55	70	72	72	71	72
65	45	45	43	42	42
75	29	29	27	27	27
85	19	19	18	18	18
90	18	18	18	18	18

Illuminance at Distance





Coefficients Of Utilization - Zonal Cavity Method

								Effec	tiv	e F1	oor	Cav	ity	Ref	lecta	ance	: 2	0%	١
RCC %:		8	0			7	0			50			30			10		0	F
RW %:	70	50	30	0	70	50	30	0	50	30	20	50	30	20	50	30	20	0	L
RCR: 0				119								106		106	102	102	102	100	ĮF
1	114	111	108	106	111	109	106	94	105	103	101	101	100	98	97	96	95	94	1
2			100		106			88	99			96		91	93	91	89	88	ı
3	103				101	96	91	83	93		87	91	88	85	89		84	82	ı
4	99	92	86		97	90	86	79	88	84	81	86		80	84	82	79	78	П
5	94			77	93		80	74	84			82			81	77	75	73	ı
6	90		76		89		76	70	80			78	74	71	77	73	71	69	ı
7	86	78	72		85	77	72	67	76	71	68	75	70	67	74	70	67	66	П
8	83	74	68	65	82	73	68	64	72	68	64	71	67	64	70	67	64	62	ı
9	79	70	65		78	70	65	61	69			68		61	67	64	61	59	ı
10	76	67	62	58	75	67	62	58	66	61	58	65	61	58	65	61	58	57	1

Zonal Lumen


	Z	one	Lumens	%	Fixtu	^e
0	-	60	3934.8		97.7	%
60	-	90	93.2		2.3	%
0	-	90	4028.1		100.0	%

63° spread lens




LED	Lumens	Efficacy
RGB	4009	31.5

Polar Candela Distribution



	0	25	45	70	90	
0	4733	4733	4733	4733	4733	
5	4524	4533	4551	4586	4611	
15	3543	3568	3595	3658	3722	
25	2269	2219	2204	2231	2285	
35	1149	1062	1016	1000	1025	
45	473	405	367	350	358	
55	172	140	124	116	119	
65	70	61	56	51	50	
75	35	31	28	25	24	
85	18	17	17	16	16	
90	16	0	0	0	0	

Illuminance at Distance



Coefficients Of Utilization - Zonal Cavity Method

									Effec	ctiv	e F1	oor	Cav	ity	Ref	ecta	ince	: 2	0%	
RCC	%:		6	0			7	0			50			30			10		0	
RW		70	50	30	0	70	50	30	0	50		20	50	30	20	50	30	20	0	
RCR:	0	119	119	119	119	116	116	116	100	111	111	111	106	106	106	102	102	102	100	
					104	110	108	105	92	103	101	100	100	98	97	96	95	94	92	
		106	101	97	93	104	99	95	85	96	93	90	93	90	88	90	88	86	84	
	3	101	93	88	84	98	92	87	78	89	85	82	87	83	80	85	82	79	77	
	4	95	87	81	76	93	86	80	73	83	79	75	81	77	74	79	76	73	71	
	5	90	81	74	70	88	80	74	67	78	73	69	76	72	68	75	71	68	66	
	6	85	75	69	64	83	75	68	63	73	68	64	72	67	63	70	66	63	61	
	7	81	71	64	60	79	70	64	58	69	63	59	67	62	59	66	62	58	57	
	8	76	66	60	56	75	66	60	55	65	59	55	64	59	55	63	58	55	53	
	9	73	62	56	52	72	62	56	51	61	56	52	60	55	52	59	55	51	50	
	10	69	59	53	49	68	59	53	48	58	52	49	57	52	48	56	52	48	47	

Zonal Lumen


	Z	one	Lumens	%	Fixtu	re
0	-	60	3877.6		96.7	%
60	-	90	131.0		3.3	%
0	_	90	4008.6		100.0	%

5x17° spread lens




LED	Lumens	Efficacy
RGB	4084	32.1

Polar Candela Distribution



	0	25	45	70	90
0	96765	96765	96765	96765	96765
5	69434	57305	38831	23251	20218
15	9262	1558	619	428	416
25	572	191	161	150	153
35	166	99	91	79	82
45	98	56	49	46	46
55	66	39	34	35	35
65	46	31	27	26	25
75	30	24	22	21	21
85	20	19	20	20	20
90	19	0	0	0	0

Illuminance at Distance



24 π

311 ft (94.7 m)

1 vert. Spread: 16.5°
1 fc maximum distance

1 Horiz. Spread: 6.3°

Coefficients Of Utilization - Zonal Cavity Method

								Effec	tiv	e Fi	loor	Cav	rity	Ref	lect	ance	: 2	0%
RCC %:		8	0			7	0			50			30			10		0
RW %:	70	50	30	0	70	50	30	0	50	30	20	50	30	20	50	30	20	0
RCR: 0					116				111					106				100
					113											100	99	98
2	113	109	107	105	111	108	105	96	105	103	101	102	100	99	99	98	97	96
3	110	106	103	101	108	105	102	95	102	100	98	100	98	97	98	97	95	94
4	108	103	100	98	106	102	99	94	100	98	96	99	97	95	97	95	94	93
5	106	101	98	95	104	100	97	92	99	96	94	97	95	93	96	94	93	92
6	104	99	96	94	103	98	95	91	97	95	93	96	94	92	95	93	92	91
	102	97	94	92	101	97	94	90	96	93	91	95	93	91	94	92	91	90
	101	96	93	91	100	96	93	90	95	92	90	94	92	90	93	91	90	89
9	99	95	92	90	99	94	91	89	94	91	89	93	91	89	92	90	89	88
10	98	93	91	89	98	93	90	88	93	90	88	92	90	88	91	89	88	87


Zonal Lumen

	Z	one	Lumens	%	Fixture
0	-	60	4008.1		98.1 %
60	-	90	75.8		1.9 %
Ω	_	90	4083.9		100.0 %

Specifications, UL / CE


Due to continuous improvements and innovations, specifications may change without notice.


ltem	Specification	Details				
recin	Beam Angle	5° native 8°, 13°, 23°, 40°, 63°, and 5° x 17° (asymmetric) spread lenses				
Output	Lumens*	4,505 (full unit, no spread lens)				
	LED Channels	Red / Green / Blue				
	Lumen Maintenance†	100,000 hours L ₇₀ @ 25° C 100,000 hours L ₇₀ @ 50° C				
Electrical	Input Voltage	100 – 277 VAC, auto-ranging, 50 / 60 Hz via Data Enabler Pro				
Electrical	Power Consumption	135 W				
	Interface	Data Enabler Pro (DMX / Ethernet)				
Control	Control System	Philips Color Kinetics full range of controllers, including Light System Manager, iPlayer 3, and ColorDial Pro, or third-party controllers				
	Dimensions Height x Width x Depth	8.5 x 28.9 x 7.7 in (217 x 733 x 196 mm)				
	Weight	51 lb (23 kg)				
	Effective Projected Area (EPA)	0.186 m ²				
	Housing	Die-cast aluminium, powder-coated finish				
	Lens	Tempered glass				
Physical	Fixture Connections	Integral male / female waterproof connector, 6 ft (1.8 m) unified power / data cable				
	Temperature Ranges	-40° – 122° F (-40° – 50° C) Operating -4° – 122° F (-20° – 50° C) Startup -40° – 176° F (-40° – 80° C) Storage				
	Humidity	0 – 95%, non-condensing				
	Fixture Run Lengths	To calculate fixture run lengths and total power consumption for your specific installation, download the Configuration Calculator from www.philipscolorkinetics.com/support/install_tool/				
Certification	Certification	UL / cUL, FCC Class A, CE, PSE				
and Safety	Environment	Dry / Damp / Wet Location, IP66				



 $www.philips color kinetics.com/support/appnotes/lm-80-08.pdf \ for \ more \ information.$

CHROMACORE OPTIBIN POWERCORE CKTECHNOLOGY





^{*} Lumen measurement complies with IES LM-79-08 testing procedures


[†] L70 = 70% lumen maintenance (when light output drops below 70% of initial output). Ambient luminaire temperatures specified. Lumen maintenance calculations are based on lifetime prediction graphs supplied by LED source manufacturers. Calculations for white-light LED fixtures are based on measurements that comply with IES LM-80-08 testing procedures. Refer to

Specifications, CQC


Due to continuous improvements and innovations, specifications may change without notice.

Item	Specification	Details					
	Beam Angle	5° native $8^{\circ}, 13^{\circ}, 23^{\circ}, 40^{\circ}, 63^{\circ},$ and $5^{\circ} \times 17^{\circ}$ (asymmetric) spread lenses					
Output	Lumens*	4,505 (full unit, no spread lens)					
	LED Channels	Red / Green / Blue					
	Lumen Maintenance†	100,000 hours L ₇₀ @ 25° C 100,000 hours L ₇₀ @ 50° C					
Electrical	Input Voltage	100 – 240 VAC, auto-switching, 50 / 60 Hz via Data Enabler Pro					
Electrical	Power Consumption	130 W					
	Interface	Data Enabler Pro (DMX / Ethernet)					
Control	Control System	Philips Color Kinetics full range of controllers, including Light System Manager, iPlayer 3, and ColorDial Pro, or third-party controllers					
	Dimensions Height x Width x Depth	8.5 x 28.9 x 7.7 in (217 x 733 x 196 mm)					
	Weight	51 lb (23 kg)					
	Effective Projected Area (EPA)	0.186 m ²					
	Housing	Die-cast aluminium, powder-coated finish					
	Lens	Tempered glass					
Physical	Fixture Connections	Integral male / female waterproof connector, 6 ft (1.8 m) unified power / data cable					
	Temperature Ranges	-40° – 122° F (-40° – 50° C) Operating -4° – 122° F (-20° – 50° C) Startup -40° – 176° F (-40° – 80° C) Storage					
	Humidity	0 – 95%, non-condensing					
	Fixture Run Lengths	To calculate fixture run lengths and total power consumption for your specific installation, download the Configuration Calculator from www.philipscolorkinetics.com/support/install_tool/					
Certification	Certification	CE, CQC, FCC Class A, PSE					
and Safety	Environment	Dry / Damp / Wet Location, IP66					

CHROMACORE* OPTIBIN[®] POWERCORE*



5° x 17°



^{*} Lumen measurement complies with IES LM-79-08 testing procedures † L70 = 70% lumen maintenance (when light output drops below 70% of initial output). Ambient luminaire temperatures specified. Lumen maintenance calculations are based on lifetime prediction graphs supplied by LED source manufacturers. Calculations for white-light LED fixtures are based on measurements that comply with IES LM-80-08 testing procedures. Refer to www.philipscolorkinetics.com/support/appnotes/lm-80-08.pdf for more information.

Fixture and Accessories

ColorReach Compact Powercore fixtures are part of a complete line-voltage system which includes fixtures and:

- · One or more Data Enabler Pro devices.
- Any Philips Color Kinetics controller, including Light System Manager, iPlayer 3, and ColorDial Pro, or a third-party controller.
- One 1.8 m (6 ft) leader cable to connect each ColorReach Compact Powercore fixture to a junction box or Data Enabler Pro.
- 4-conductor copper wire to connect ColorReach Compact Powercore fixtures in series or in parallel. Standard 12 AWG (2.05 mm) stranded wire is recommended.

Item	Туре		Item Number	Philips 12NC	
ColorReach Compact	UL / cUL		123-000154-00	912400130183	
Powercore Includes 10 ft (3 m) leader cable	CE / PSE		123-000154-01	912400130195	
ColorReach Compact Powercore Includes 6 ft (1.8 m) leader cable	CQC		123-000078-02	912400130193	
Leader Cable,	UL	3 m (10 ft)	108-000055-03	910503704066	
100–277 V,AC	OL	15.2 m (50 ft)	108-000055-00	910503703137	
UL / CE	CE / PSE	3 m (10 ft)	108-000055-04	910503704067	
OL / CE	CE / F3E	15.2 m (50 ft)	108-000055-01	910503704064	
Leader Cable, 100–240 VAC, CQC	CQC / CE	1.8 m (6 ft)	108-000043-03	910503700454	
	13°		120-000068-00	910503700506	
	23°		120-000068-01	910503700507	
Canad Languish hazal	40°		120-000068-02	910503700508	
Spread Lens with bezel	63°		120-000068-03	910503700509	
	Asymmetric	(5° × 17°)	120-000068-04	910503700510	
	8°		120-000068-05	910503700511	
Data Enabler Pro	3/4 in / 1/2 ii (U.S. trade si		106-000004-00	910503701210	
Data Enabler Pro	PG21 / PG13 (metric size		106-000004-01	910503701211	

Use Item Number when ordering in North America.

Custom Configurations

In addition to the standard configurations listed here, custom configurations are also available with a non-standard color and color temperature. See the ColorReach Compact Powercore Ordering Information sheet at www.philipscolorkinetics.com/ls/rgb/colorreachcompact/ for complete details.

Component	Available Non-Standard Options
Color Temperature	2700K, 3000 K, 3500 K, 4000 K, 5000 K, 5500 K, 6000 K, 6500 K
Color	Royal Blue, Blue, Green, Amber, Red

Installation

ColorReach Compact Powercore, a high-performance exterior architectural floodlight with light projection of up to 448 ft (136.6 m), is designed to brilliantly and dynamically illuminate prominent, signature façades. Because each ColorReach Compact Powercore fixture weighs 51 lb (23 kg), you may need two people to lift the fixture out of the box and position it in the mounting location. Optional accessory optics require the installation of both a spread lens and a bezel on each half of the fixture.

Owner / User Responsibilities

It is the responsibility of the contractor, installer, purchaser, owner, and user to install, maintain, and operate ColorReach Compact Powercore fixtures in such a manner as to comply with all applicable codes, state and local laws, ordinances, and regulations. Consult with the appropriate electrical inspector to ensure compliance.

Installing in Damp or Wet Locations


When installing in damp or wet locations, you must seal all junction boxes and Data Enabler Pro devices with electronics-grade RTV silicone sealant so that water or moisture cannot enter or accumulate in wiring compartments, cables, fixtures, or other electrical parts. You must use suitable outdoor-rated junction boxes when installing in wet or damp locations. Additionally, you must use gaskets, clamps, and other parts required for installation to comply with all applicable local and national codes.

Prepare for the Installation

1. Refer to the lighting design plan, architectural diagram, or other diagram that shows the physical layout of the installation to identify the locations of all switches, controllers, Data Enabler Pro devices, fixtures, and cables.

ColorReach Compact Powercore fixtures can be installed in series or in parallel (wired to a common junction box). The maximum number of fixtures each Data Enabler Pro can support depends on specific configuration details such as fixture spacing, circuit size, line voltage, and method of connection (in series or in parallel). For more information, and for help calculating the number of fixtures your specific installation can support, download the Configuration Calculator from www.philipscolorkinetics.com/support/install tool/, or consult Application Engineering Services at support@colorkinetics.com.

In addition to maximum fixture run lengths determined by the electrical configuration, each Data Enabler Pro imposes maximum run lengths based on data integrity. To ensure data integrity, maximum individual run length should not exceed 175 feet (53.3 m), and the total cable length per Data Enabler Pro should not exceed 400 feet (122 m).



Data Integrity - maximum individual length 175 ft (53.3 m)

Data Integrity - total length 400 ft (122 m)

Refer to the ColorReach Compact Powercore Installation Instructions for specific warning and caution statements.


 To streamline the configuration of complex installations, record the serial number (DMX) or IP address (Ethernet)

and location of each Data Enabler Pro..

- 2. Ensure that the fixture mounting locations and substrates are sufficiently sturdy to bear the weight of each ColorReach Compact Powercore fixture. Pre-drill holes in the mounting substrate if necessary, making reference to the mounting bracket dimensions. Use at least two screws to secure each fixture, one on either side of the mounting bracket's central screw hole.
 - If mounting ColorReach Compact Powercore on a lighting pole, make sure the pole can both support the total weight of the fixtures and withstand the maximum velocity winds to which it will be subjected. Each fixture weighs 51 lb (23 kg), and has an effective projected area (EPA) of 0.186 m².
- 3. Install all Data Enabler Pro devices, including any interfaces with controllers. Data Enabler Pro and external controllers send power and control signals to fixtures over the single leader cable.
- 4. Verify that all additional supporting equipment (switches, controllers) is in place.
- 5. Ensure that all additional parts and tools are available, including:
 - A 28 mm hex or adjustable wrench for adjusting the locking bolts on the fixture bracket.
 - One electrical junction box per fixture, rated for your application. (Refer to the junction box manufacturer's literature for additional items required for mounting or sealing.)
 - A sufficient length of 4-conductor copper wire. We recommend 12 AWG (2.05 mm) stranded wire.
 - · Conduit as required.
 - · Electronics-grade room temperature vulcanizing (RTV) silicone sealant.


Unpack the Fixtures


- Unpack ColorReach Compact Powercore fixtures. Because each ColorReach Compact Powercore fixture weighs 51 lb (23 kg), you may need two people to lift the fixture out of the box and position it in the mounting location.
- Each ColorReach Compact Powercore fixture comes pre-programmed with a unique serial number. As you unpack the fixtures, record the serial numbers in a layout grid (typically a spreadsheet or list) for easy reference and light addressing.
- 3. Assign each fixture to a position in the lighting design plan.



4. To streamline installation and aid in light show programming, you can affix a weatherproof label identifying the order or placement in the installation to an inconspicuous location on each light fixture's housing.

Mounting bracket dimensions for pre-drilling






② Do not rest ColorReach Compact Powercore on its back, as doing so may damage the connector port. Be careful not to tip the fixture over during positioning.


Attach Spread Lenses (Optional)


Exchangeable ColorReach Powercore gen2 spread lenses of 8° , 13° , 23° , 40° , 63° , and an asymmetric $17^{\circ} \times 5^{\circ}$ support a variety of photometric distributions for a multitude of applications, including spotlighting, wall grazing, and asymmetric wall washing. Each half of ColorReach Powercore gen2 can be individually addressed and controlled, and you can install different spread lenses on each half of the fixture's housing for precise control of light diffusion.

- 1. Unpack and confirm the contents of the box. Each box contains one lens kit, consisting of a spread lens with attached rubber gasket, and a bezel with 10 captured mounting screws.
- 2. Clean both sides of the spread lens and the face of the ColorReach Powercore gen2 housing, including glass surfaces, using a mild, non-abrasive cleaner. Ensure that all surfaces are dry, and that the gasket is properly fitted to the lens.
- 3. Position the spread lens so that the beam-angle designation on the side of the lens is face up. Handle the spread lens by the gasket, making sure not to touch or soil either surface of the spread lens.




4 Place the spread lens on top of the ColorReach Powercore gen2 housing. Make sure that the spread lens and gasket are seated properly within the fixture housing. Also make sure that there is no moisture between the spread lens and the glass, as any moisture will compromise the effectiveness of the spread lens.






For installation in extreme environments, refer to the Reach Spread Lens Kit Installation Instructions for details on sealing the spread lens and bezel to prohibit water ingress.


5. Position the bezel over the spread lens.



6. With a standard #2 Phillips screwdriver, attach the bezel to the fixture housing using the screws provided. To ensure a watertight seal, tighten the screws to approximately 20-30 in-lbs (2.2-3.4 Nm) in the sequence shown below.




Leader Cable connector dimensions




Position and Mount Fixtures

- 1. Position each ColorReach Compact Powercore fixture in its designated mounting location. Make sure the mounting area is clear of debris and other obstructions.
- Loosen the locking bolts, using a 28 mm hex or adjustable wrench, and rotate the fixture to access the mounting bracket. Tilting the fixture 90° affords 9.1 in (231 mm) clearance.



3. If mounting holes have been pre-drilled, align the mounting bracket's screw holes with the pre-drilled holes. Mount the fixture bracket using hardware appropriate for the mounting substrate. Use at least two screws to secure each fixture, one on either side of the mounting bracket's central screw hole.



Connect the Fixtures

Make sure the power is OFF before connecting ColorReach Compact Powercore fixtures.

- 1. Mount junction boxes in accordance with the lighting design plan.
- 2. If installing fixtures in a series, pull 4-conductor copper wire between each junction box in the series.


If installing fixtures in parallel, pull 4-conductor copper wire from a common junction box to each fixture's junction box.

The maximum cable run from a Data Enabler Pro to any individual ColorReach Compact Powercore fixture is 175 feet (53 m). When installing in parallel, the total cable length cannot exceed 400 feet (122 m).


3. If necessary, remove the connector cap from the port on the back of the ColorReach Compact Powercore housing. Insert the leader cable into the port. Turn the leader cable's lock nut to the right until it locks into place.




- 4. Use wire nuts to connect line, neutral, ground, and data. If installing in series, connect the leader cable from each fixture to the fixture's junction box.
 - If installing in parallel, connect the leader cable from each fixture to the lead wire from the Data Enabler Pro in the common junction box.
- 5. Tuck wire connections into the junction box.
- Seal all junction boxes with electronics-grade RTV silicone sealant. Use gaskets, clamps, and other parts and fittings required to comply with local outdoor wiring codes.




7. Run the wiring from the first junction box in the series to the Data Enabler Pro, or, if installing in parallel, run the wiring from the common junction box to the Data Enabler Pro. Secure connections within the Data Enabler Pro housing.




8. Secure the Data Enabler Pro cover. Seal the Data Enabler Pro with electronics-grade RTV silicone sealant.



UL / CE (100-277 VAC)



CQC (100-240 VAC)



ColorReach Compact Powercore fixtures installed in parallel

Address the Fixtures

Make sure the power is ON before add

Make sure the power is ON before addressing and configuring fixtures.

ColorReach Compact Powercore fixtures operate in 8-bit mode by default. You can configure ColorReach Compact Powercore to operate in 16-bit mode, which increases fixture resolution for smoother dimming.

In 8-bit mode, fixtures use one DMX address per LED channel (red, green, and blue). In 16-bit mode, fixtures use two DMX addresses per LED channel. The first DMX address corresponds to the "coarse" data for that channel, and the second corresponds to the "fine" data. By using double the number of DMX addresses, 16-bit mode increases fixture resolution from 256 dimming steps to 65,536 (256 \times 256) dimming steps.

DMX Channel Assignments										
8-Bit Mode	1	ſ	2	!	3					
O-Dit i lode	Re	ed	Gre	een	Blue					
16-Bit Mode	1	2	3	4	5	6				
16-bit 110de	Red Coarse	Red Fine	Green Coarse	Green Fine	Blue Coarse	Blue Fine				

Each 1 ft (305 mm) ColorReach Compact Powercore node comes factory-addressed with a starting DMX address of 1. For lighting designs where fixture nodes work in unison, all nodes can be assigned the same DMX addresses. Changes to the default addresses are not necessary, but if nodes were previously readdressed for use in other installations, you must reset them. For light show designs that show different colors on different nodes, you must assign unique DMX addresses to your nodes and sort them in a useful order.

- In Ethernet installations, you can address and configure fixture nodes using
 QuickPlay Pro with a computer connected to your lighting installation's network.
 QuickPlay Pro can automatically discover all fixture nodes, controllers, and Data
 Enabler Pro devices for quick configuration.
- In DMX installations, you can address and configure fixture nodes using QuickPlay Pro with iPlayer 3 or SmartJack Pro. You can manually enter fixture node serial numbers, or you can import a spreadsheet listing each fixture node's serial number and starting DMX address.


For details on addressing and configuring fixtures, controllers, and power / data supplies with QuickPlay Pro, refer to the Addressing and Configuration Guide, which you can view or download at www.philipscolorkinetics.com/support/addressing.

- ☼ You can address fixtures and switch between 8-bit mode and 16-bit mode using QuickPlay Pro.You can download QuickPlay Pro from www.philipscolorkinetics.com/ support/addressing/
- You will need the layout grid that you created when you recorded the serial numbers of the light fixtures in your installation.

Aim and Lock the Fixtures


Make sure power is ON before aiming fixtures.

- 1. Aim the fixtures by rotating each fixture to the correct angle.
- 2. Lock the fixtures by tightening the locking bolts using a 28 mm hex or adjustable wrench.



② Do not look directly into the fixture when aiming and locking.

☼ For exterior applications with direct exposure to water, ColorReach Compact Powercore fixtures should not be aimed directly upwards, as water may pool on the lens and affect beam quality. Instead, the fixture should be angled to allow for proper water drainage.





Philips Color Kinetics 3 Burlington Woods Drive Burlington, Massachusetts 01803 USA Tel 888.385.5742 Tel 617.423.9999 Fax 617.423.9998 www.philipscolorkinetics.com